


EZSTAT DIGITAL CONTROLS

FAN COIL UNITS WITH EPIC ECM

MODEL SERIES: 35FH, 37FH AND 39 (TYPE Z)

CONTROL SEQUENCE: N510 (2-PIPE)



N510 BACnet DIGITAL THERMOSTAT 7-DAY PROGRAMMABLE SCHEDULE VARIABLE AIR VOLUME, MODULATING COOLING • 2-PIPE SYSTEM

Discharge Air Temperature

The Discharge Air Temperature sensor (DAT) provides the controller with the coil leaving air temperature (LAT). This is used to control the modulating valve to achieve a pre-set, but adjustable, discharge temperature. On cooling, this controls humidity.

SEQUENCE OF OPERATION:

Modulating Cooling

On a call for cooling, the chilled water valve will begin to modulate open. The valve will continue to open until the discharge air temperature reaches 52°F (11°C). Simultaneously, the fan will modulate from minimum airflow to maximum airflow to achieve room set point. Upon a decrease in cooling demand, the sequence will reverse.

Deadband

With no demand in the space, there will be no call for cooling. The fan will be at a deadband set minimum airflow. The chilled water valve will be off.

Notes:

- EZstat is factory programmed for the specific sequence of operation.
- EZstat is also factory calibrated when airflow settings are provided for easy start-up.
- 3. Field commissioning (password protected):
 - Max. and Min. airflow settings are field adjustable between the ranges on the unit's ECM fan curve calibration chart.
 - b. Deadband differential and other parameters are also adjustable.
 - c. Refer to EZstat Application Guide/IOM.
- 4. Remote mounted 24 VAC thermostat is field wired (by others). Refer to application specific wiring diagram.
- 5. Thermostats baseplate mounts to a standard 2" (51) x 4" (102) vertical handy box.







SCHEDULE TYPE:	Dimension are in inches (mm).			
PROJECT:	Dimension are in inches (min).			
ENGINEER:	DATE	B SERIES	SUPERSEDES	DRAWING NO.
CONTRACTOR:	9 - 23 - 14	FCS	NEW	FCS-N510